

# Detector Control System for the 2017 Run

DCS phones: **164872** (+41754114872), **77076** (+41227677076)

## Contents

1	WinCCOA DCS project	2
2	SLiC	7
3	OPC	12
4	Siemens S7	17
5	Modbus	18
6	DIP	19
7	DIM	20
8	Databases	21
9	CAEN	22
10	ISEG	24
11	Wiener VME and LV	25
12	ELMB	26
13	Misc.	27

# 1 WinCCOA DCS project

The DCS uses two main Linux PCs:

- **pcompass07**, main computer, located in the 888 control room.
- **pcompass04**, located in the 888 control room.

4 other Linux PCs are used for front-ends (CAEN control using SLiC/DIM):

- **pclip05** (BMS barrack),
- **pclip07** (DCS & Saclay barrack),
- **pclip09** (RICH barrack),
- **pclip010** (Trigger barrack).

3 other Windows PCs are used for front-ends (all controls from OPC servers):

- **pcompass03**,
- **pcompass06**,
- **pcompass08**,

The 3 Windows PCs are located in the DCS & Saclay barrack, in the left racks.

## 1.1 Starting the project

- Switch on all the DCS PCs.
- pccompass07
  - Login as compassdcs;
  - From terminal, start the DIM NAME SERVER (dns):  
> dns &
  - From the terminal, start the WinCC OA console:  
> startConsole
  - Start the project and check that all the important managers are started:
    - \* Process Monitor 1
    - \* Database Manager 0
    - \* RDB Archive Manager 99
    - \* Event Manager 0
    - \* Control Manager 1
    - \* Simulation Driver 1
    - \* Distribution Manager 1
    - \* Simulation Driver 13 (for DIP)
    - \* Control Manager 6 (Compass\_Survey.ctl)
    - \* Control Manager 7 (smsTrigger.ctl, might want to wait to avoid fake notifications)
    - \* Control Manager 3 (SetTime.ctl)
    - \* Control Manager 4 (hvChlsOnGuardian.ctl)
    - \* WCCOAnmr 1
    - \* Control Manager 12 (Power\_Switches\_Status.ctl)
    - \* Modbus Driver 3
    - \* Control Manager 14 (DIP\_status.ctl)
    - \* Control Manager 16 (Ecal1\_Hv\_Laser\_isOn.ctl)
    - \* Control Manager 18 (Ecal2\_position.ctl)
    - \* Control Manager 19 (Ecal1\_position.ctl)
    - \* Control Manager 20 (DAQ\_SpillBuffer\_Watchdog.ctl)
    - \* Control Manager 21 (RunInformation.ctl)
    - \* WCCOAdim 14
    - \* Control Manager 22 pccodb00\_status.ctl

- \* Control Manager 23 Tgt\_Hydrogen.ctl
- \* WCCOAdim 16
- \* WCCOAdim 17
- \* Control Manager 25 nmrNodeDuringSpill.ctl
- \* Control Manager 26 DC0001Lv.ctl
- Start the reading of SM2 magnetic field from NMR meter.
- Start the PMM Lv control and monitoring.
- Open a DCS UI and start the remaining managers when everything else has been started.

- pccompass04
  - From the terminal and as compassdcs, start the WinCC OA console.  
> startConsole
  - Start the project and check that all the important managers are started:
    - \* Process Monitor 1
    - \* Database Manager 0
    - \* RDB Archive Manager 99
    - \* Event Manager 0
    - \* Control Manager 1
    - \* Simulation Driver 1
    - \* Distribution Manager 1
    - \* Control Manager 3 (unDistributedControl.ctl)
    - \* Control Manager 20 (Beamdb2014.ctl)
    - \* Control Manager 28 (SetTime.ctl)
    - \* Control Manager 29 (SumAlertsToDCS1.ctl)
    - \* Control Manager 16 (Ecal1Script.ctl)
    - \* Control Manager 17 (Ecal2Script.ctl)
    - \* Control Manager 26 (Hcal1Script.ctl)
    - \* Control Manager 27 (Hcal2Script.ctl)
    - \* Control Manager 18 (Ecal0Script.ctl)
- pccompass03, pccompass06, pccompass08
  - From the terminal:
    - > rdesktop pccompass0X -g '90%' &
  - Login as compassdcs and start the WinCC OA console.
- pclip05, pclip07, pclip09, pclip010
  - Login as root and start the SLiC(s).
  - Check on pccompass07 with did before starting the DIM managers:
    - > did &

## 1.2 Offline copy

pccompass04, pccompass07:

- Login in pccompass0X.
- Stop the WinCC OA project. Close the WinCC OA admin console.
- Kill the remaining WinCC OA processes:
  - > ps -ef | grep WinCC\_OA - (only lm\_ip -a lockmgr shall appear)
- Go to the /dcs/projects directory
- In the following directories remove the old versions of files:
  - /dcs/projects/compassdcs/panels
  - /dcs/projects/compassdcs/panels/objects
  - /dcs/projects/compassdcs/log
- As root, create the backup and move it to /dcs\_Backup/offline\_backups:
  - > cd /dcs/projects
  - > gtar --atime-preserve --preserve-permissions --same-owner -cvf comp0X-copy[date].tar compassdcs/
  - > gzip comp0X-copy[date].tar
  - > mv comp0X-copy[date].tar.gz /dcs\_Backup/offline\_backups/
  - > cd /dcs/packages
  - > gtar --atime-preserve --preserve-permissions --same-owner -cvf comp0X-jcop-copy[date].tar jcop\_fw/
  - > gzip comp0X-jcop-copy[date].tar
  - > mv comp0X-jcop-copy[date].tar.gz /dcs\_Backup/offline\_backups/

## 2 SLiC

6 SLiCs exist at the moment, and for each there is a corresponding DIM API manager in WinCC OA.

When the DIMs are stopped or started, from the DCS panel of the project, there is no effect on the SLiCs.

To start or stop SLiC one must login as root in the corresponding linux PCs, and do it manually.

If in pccompass07 CAEN HV tables show the purple color in all fields (v0, vMon, iMon) and if DIMs are running (check in the DCS panel of the project) and dns is running it probably means that SLiC is stopped.

To check if dns is running in pccompass07:

```
>ps -ef | grep dns
```

### 2.1 Loading a1303 driver

Login as root in the SLiC PC:

- > cd /home/SLiC
- > source env.bash
- > cd /home/beharel/projects/HSCAENETLib-1-7/driver/
- > ./a1303\_load.2.6
- > cat /proc/a1303

### 2.2 Generating SLiC configuration

Login as root in the SLiC PC:

- > cd /home/SLiC
- > ./generateConfigurations.pl configParams.txt configInit.txt  
config.txt dimMap.txt
- > ./generateConfigurations.pl ./config2ndSLIC/configParams.txt  
./config2ndSLIC/configInit.txt ./config2ndSLIC/config.txt  
./config2ndSLIC/dimMap.txt (if it applies)

## 2.3 Starting SLiC

Login as root in the SLiC PC:

- `> cd /home/SLiC`
- `> source env.bash`
- `> ./SLiCapp ./config.txt ./ ./dimMap.txt >/dev/null &`
- `> ./SLiCapp config2ndSLIC/config.txt ./ config2ndSLIC/dimMap.txt >/dev/null &` (if it applies)

## 2.4 Killing SLiC

Login as root in the SLiC PC:

- `> ps -ef | grep SLiC`
- `> kill -9 pid`
- `> cd /home/SLiC`
- `> source env.bash`
- `> ./semaphoreClear.pl`

## 2.5 List of SLiCs

Next is a list of the current SLiC servers.

**pclip05:**




Figure 1: DIM\_1.



pclip010:




Figure 2: DIM\_2.




Figure 3: DIM\_3.

pclip07:




Figure 4: DIM\_4.

pclip09:




Figure 5: DIM\_5.




Figure 6: DIM\_6.

### 3 OPC

3 Windows 7 PCs are used to run OPC servers and WinCC OA OPC clients.  
**pccompass03:**




Figure 7: ISEG.




Figure 8: CAEN 1.




Figure 9: WIENER3.

pccompass06:




Figure 10: SCHNEIDER.




Figure 11: WIENER2.

pccompass08:




Figure 12: CAEN 2.

Hardware controlled by CANOpen OPC Server

DCS barrack

CANbus

ELMS	Bus	Location	Detector	Sensor type
1-2		Gallery	RICH Wall	LV
2-2		MW1 FE LV power supply rack, SM2 region, Jura side.	MW1	LV.PT4W
3-1		BMS electronics room	RICH (water circulator); Env. MV LV Alarm gas system.HV.PT4W	
4-2		MW1 FE LV power supply rack, SM2 region, Salve side.	MW1	LV.PT4W
5-2		SCIFIG FE LV power supply rack, SM2 region, Salve side.	SM2, hall temperature	PT4W
6-2		Straw frame, Jura side.	Straw3	PT4W:Humidity sensor
7-2		RICH rack, Salve side.	RICH.ECal	PT4W
8-2		SCIF rack, Salve side.	Target SM1 Silicon	PT4W:SM1 Hall probes.Pol.Target flow control/gas outlets
9-1		BMS HV room (HNB202)	Bands, Cedars Env.	LV.PT4W
10-2		MMDCs electronics rack, Salve side.	SM1, hall conditions	PT4W:Humidity and pressure sensors
11-1		MWPC power supply rack, Salve side.	MWPC station 8	LV
12-1		MWPC power supply rack, Salve side.	MWPC stations 8,9,10	LV.PT4W
13-2		MWPC power supply rack, Jura side.	MWPC stations 2,3,5,6, SM2	LV.PT4W
14-2		MWPC power supply rack.	MWPC stations 4,5,6, SM2	LV.PT4W
15-2		On gallery, Jura side.	MWPC station 1	LV.PT4W
16-1		Trigger room (HNB422).		
17-2		Polarized targets Pump room	Polarized target	PT4W
18-1		Trigger room (HNB428)	ECal; ECal Env.	PT4W:LV.Voltage from ECal laser:Humidity sensors.
19-1		MW2 power supply rack (H23), Salve side.	MW2	LV.PT4W
20-1		W45 power supply rack, Salve side.	W45	LV.PT4W
21				
22-2		Straw 6 frame, Salve side.	Straw 6 and DL16	PT4W:Humidity sensor.
23-1		W45 power supply rack, Salve side.	W45, Env.	PT4W
24-2		On gallery, Jura side.	DCs	PT4W
25-2		RICH rack, Salve side.	RICH	PT4W
26-3		Silicon rack, under target platform.		
27-3		Silicon rack, under target platform.		
28-3		Silicon rack, under target platform.		
29-2		Straw frame.	Straw 2	PT4W:Humidity sensor.
30-2		Straw frame.	Straw 2	PT4W:Humidity sensor.
31-2		Close to DC4, Jura side.	DC4, SM1; raw water	PT4W
32-1		W45 rack	ECal; Env.	LV.PT4W
33-1		W45 rack	ECal; Env.	LV
34-1		W45 rack	ECal; Env.	LV
35-1		W45 rack	ECal; Env.	LV
36-2		HCALL Jura side	HCALL	LV
37-2		MMDCs electronics rack, Salve side.	DC0;DC01	PT4W

Close

Figure 13: CANOPEN.




Figure 14: WIENER1.



## 4 Siemens S7

The Liquid Hydrogen Target is monitored via WinCC OA Siemens S7 driver:




Figure 15: Siemens S7.

## 5 Modbus

The Silicon Cryogenics monitoring is performed via Modbus:




Figure 16: MODBUS3.

## 6 DIP

In the DCS, the monitoring of the beam line, radiation levels and some Silicon Cryogenics information is done via CERN DIP servers.




Figure 17: DIP\_7.

## 7 DIM

In addition to the DIM clients and servers used for SLiC, other DIM clients and servers are used by the DCS:

- **DIM\_11**
  - DAQ disks information.
  - xCals indirect monitoring via MySQL update time.
- **DIM\_13**
  - DCs thresholds.
  - PMM Lv.
- **DIM\_14**
  - spill structure
- **RICH** (still being commissioned)
  - publication of DCS RICH related temperature, humidity and pressure information.
  - subscription of RICH Hybrids related information.

## 8 Databases

### 8.1 Oracle DB

The main DCS project connects to an Oracle DB named compr. This DB is managed by CERN Physics Databases Services. A replica and read-only copy is accessible at compr\_adg.

In case the main DCS projects loses the connection to the DB, SMS and email notifications are sent and a “RDB\_99: TimeAlarm” alarm is displayed in the DCS UI. If the alarm persists:

- Find if there is a network problem or a DB problem:
  - Try to connect via sqlplus:  
    > sqlplus comp\_pvss@compr
  - Try ping to/from pccompass04 and pccompass07
  - Check the connections to oracle DB:  
    > netstat | grep itrac
- Check the WinCC OA logs:
  - Check /dcs/home/logs/PVSS-II.log
- Check the status of the RDB manager:
  - Open the WinCC OA console and check the color of the manager:  
    > startConsole

### 8.2 MySQL DB

The main DCS project connects to COMPASS MySQL DB pccodb00 to query xCals, triggers and vetos and run information.

DCS SM2 field from NMR information is copied to this database once per day.

## 9 CAEN

### 9.1 SY127, SY403 and SY527

If needed, first modify the SLiC config file to include the new channels.

In pccompass07, add the new channels to the DCS WinCC OA project:

- Identify which is the SLiC/DIM to which these channels belong:
  - For each SLiC/DIM there is an internal datapoint `_fwDimDefaultConfig#` where the mapping is stored (client services and client commands dp elements).
- Check which fwDimDefault is being used:
  - `> cd /dcs/packages/jcop_fw/scripts/libs/fwDevice`
  - `> nano fwDevice.ctl`
  - search for fwDimDefault and change it if needed.
- From startConsole, start the control manager fwScripts.lst
- Run fwCaenAddressDefaultSettings.pnl and set DIM as default address settings for CAEN hardware.
- From the fwDeviceEditorNavigator:
  - Go to the hardware view and add the crate, boards and channels if needed.
  - Set the default addresses and DP function. Do not set the default alarms.
  - Go to the logical view and add the channels.
- Go to the internal datapoint `_fwDimDefaultConfig#` and correct the client service and client commands dp elements:
  - Copy the content of these elements to kwrite/gedit (don't use nano).
  - Open did and check if the ending addresses are correct, there might be typos (ex: imon instead of IMon).
  - Copy and paste back the edited results.
- Edit panel DefCAENAlarmHandlingAndDescriptions.pnl and run it to add the alarm handling and descriptions.

- Edit the `SumAlerts_on_nodes.ctl` script and run it from terminal:
  - `> cd /dcs/home/scripts`
  - `> ./runctl SumAlerts_on_nodes.ctl`
- Check if the new channels are updating and the alarms are summed and propagating correctly.
- From the `startConsole`, restart the `hvChlsOnGuardian.ctl` manager.

## 9.2 SY1527, SY2527 and SY4527

If needed, first add the crate to the CAEN HV OPC Server Configurator on `pccompass03` or `pccompass08`.

In `pccompass07`, add the new channels to the DCS WinCC OA project:

- Run `fwCaenAddressDefaultSettings.pnl` and set OPC as default address settings for CAEN hardware.
- From the `fwDeviceEditorNavigator`:
  - Go to the hardware view and add the crate, boards and channels if needed.
  - Set the default addresses<sup>1</sup> and DP function. Do not set the default alarms.
  - Go to the logical view and add the channels.
- Edit panel `DefCAENAlarmHandlingAndDescriptions.pnl` and run it to add the alarm handling and descriptions.
- Edit the `SumAlerts_on_nodes.ctl` script and run it from terminal:
  - `> cd /dcs/home/scripts`
  - `> ./runctl SumAlerts_on_nodes.ctl`
- Check if the new channels are updating and the alarms are summed and propagating correctly.
- From the `startConsole`, restart the `hvChlsOnGuardian.ctl` manager.

---

<sup>1</sup>You might need to change the default OPC driver number and groups. This can be done via Register device type→Edit device definitions functionality of `fwDeviceEditorNavigator` before setting the addresses or via export, edit and import of a dpl file via the WinCC OA ASCII Manager.

## 10 ISEG

ISEG setup is quite stable and it's unlikely to change soon. Still, if needed login on pccompass03 and first add the module(s) with the iseg OPC Config tool.

In pccompass07, add the new channels to the DCS WinCC OA project:

- From the fwDeviceEditorNavigator:
  - Go to the hardware view and add the boards and channels if needed.
  - Set the default addresses and DP function. Do not set the default alarms.
  - Go to the logical view and add the channels.
- Edit panel DefISEGAlarmHandlingAndDescriptions.pnl and run it to add the alarm handling and descriptions.
- Edit the SumAlerts\_on\_nodes.ctl script and run it from terminal:
  - > cd /dcs/home/scripts
  - > ./runctl SumAlerts\_on\_nodes.ctl
- Check if the new channels are updating and the alarms are summed and propagating correctly.
- From the startConsole, restart the hvChlsOnGuardian.ctl manager.



## 11 Wiener VME and LV

If needed, first add the crate(s) to Wiener configuration file on pccompass03, pccompass06 or pccompass08.

In pccompass07, add the new channels to the DCS WinCC OA project:

- From the fwDeviceEditorNavigator:
  - Go to the hardware view and add the crate and channels if needed.
  - Set the default addresses<sup>2</sup> and DP function. Do not set the default alarms.
  - Go to the logical view and add the crates.
- Edit panel DefWienerAlarmHandlingAndDescriptions.pnl and run it to add the alarm handling and descriptions.
- Edit the SumAlerts\_on\_nodes.ctl script and run it from terminal:
  - > cd /dcs/home/scripts
  - > ./runctl SumAlerts\_on\_nodes.ctl
- Check if the new channels are updating and the alarms are summed and propagating correctly.

---

<sup>2</sup>You might need to change the default OPC driver number and groups. This might be done via Register device type→Edit device definitions functionality of fwDeviceEditorNavigator before setting the addresses or via export, edit and import of a dpl file via the WinCC OA ASCII Manager.

## 12 ELMB

If needed, first edit the CANOpen config file on pccompass08. This can be done by adding the ELMB(s) and channel(s) from the fwDeviceEditorNavigator with the WinCC OA simulator ON instead of the driver and creating a new config file. Then just copy the modifications to the config file on pccompass08.

In pccompass07, add the new channels to the DCS WinCC OA project:

- From the fwDeviceEditorNavigator:
  - Go to the hardware view and add the ELMB and channels if needed.
  - Set the default addresses
  - Go to the logical view and add the channels.
- Add the alarm handling and descriptions if it applies.
- Edit the SumAlerts\_on\_nodes.ctl script and run it from terminal:
  - > cd /dcs/home/scripts
  - > ./runctl SumAlerts\_on\_nodes.ctl
- Check if the new channels are updating and the alarms are summed and propagating correctly.

## 13 Misc.

### 13.1 SM2 magnetic field from NMR meter

The NMR meter is in the control room, after the DAQ computers. It is connected via RS232 (serial) to pccompass07. The reading is currently done using the port `/dev/ttyS2`.

The program to read from the port is in the directory:

```
> cd /dcs/packages/compass/nmr/bpi
```

and is called `readout_NMR`. this program must be running at all times (during Run) in pccompass07.

Check if the program is running with the command:

```
> ps -ef | grep readout
```

This program runs interactively, in a virtual screen. To enter the virtual screen (`readout`), do:

```
> screen -r
```

By doing this, you regain the view of the virtual screen. You should see the program printing text to the screen, with a new value every few seconds.

To detach from the virtual screen, do: `ctrl -a d`

Do not logout before detaching from the virtual screen first. It would kill the program.

In case the program is stopped, as "compassdcs" do:

- ```
> cd /dcs/packages/compass/nmr/bpi
```
- Reattach to the screen if it still exists, if not start a new screen:
  - ```
> screen -r
```
  - ```
> screen
```
- After entering the virtual screen:
  - ```
> ./readout_NMR
```
- After the program starts running, detach from the virtual screen with `ctrl -a d`
- On the WinCC OA side, if needed, restart the WCCOAnmr manager from the console.
- Check that the values in the DCS are updating.

## 13.2 SLC5 Custom kernel

For SLiC servers one needs to install a custom SLC5 kernel:

- `> scp compassdcspcompass07:/dcs_Backup/SLiC_backups/kernel*rpm .`
- `> rpm -Uvh --oldpackage kernel*rpm`
- `> /sbin/service yum-autoupdate stop`
- `> /sbin/chkconfig --del yum-autoupdate`
- Edit `/etc/sysconfig/yum-autoupdate`, set `update options = 0`
- `> /sbin/reboot`
- `> uname -a` (to check it's the correct kernel)
- `> grep CONFIG_HZ /boot/config-2.6.xx` (should be 100)

### 13.3 PMM Lv

This concerns the remote control of PMM Lv via an Ethernet to Digital IO Relay and DIM.

The DIM server runs on a virtual screen in pccompass07.

In case the program is stopped, as "compassdcs" do:

- > cd /dcs/packages/compass/dimPMMLV
- Reattach to the screen if it still exists, if not start a new screen:
  - > screen -r
  - > screen
- After entering the virtual screen:
  - > ./dimPMM\_LV &
- After the program starts running, detach from the virtual screen with ctrl -a d
- On the WinCC OA side, if needed, restart the dim client from the dcs UI.
- Check that the values in the DCS are updating.

## 13.4 Network ports

- Port Numbers used by WinCC OA:
  - Distribution Manager port is 4777.
  - Data Manager port is 4897.
  - Redundancy Manager port is 4899.
  - Event Manager port is 4998.
  - Pmon port is 4999.
  - Distribution Manager's alive port is 5777.
- Port Numbers used by DIM and DIP:
  - DNS default port is 2505.
  - DIM Servers will use ports in the range 5100 to 6000.
- Port Number used by Modbus is 502.

<https://wikis.web.cern.ch/wikis/display/EN/whatPortsAreUsed>  
[https://dim.web.cern.ch/dim/dim\\_info.html](https://dim.web.cern.ch/dim/dim_info.html)  
<https://wikis.web.cern.ch/wikis/display/EN/DIP+FAQ>

## 13.5 Adding a comment to COMPASS logbook

Login into COMPASS network with your personal account.


Then run:

> add\_comment

## 13.6 How to manage the rotary switches for Wiener LV PS

From Wiener Power supply PL508 manual:

All output voltages can be adjusted manually via the two rotary switches situated on the power supply top.



**This procedure of voltage adjustment is not to recommend since the min. and max. limits of the Status window have to be readjusted accordingly. Otherwise the unit will trip**

Mode Selection	Function
0-7	Adjust Voltage of U0-U7
A	CAN Address (low, Bit 0-3)
B	CAN Address (high, Bit 4-6)
C	CAN General Call Address (low, Bit 0-3)
D	CAN General Call Address (high, Bit 4-6)
E	CAN Transmission Speed Index

Figure 18: Rotary adjustments.

### CAN Transmission Speed Index

Index	Max. Distance	Bit Rate	Type
0	10 m	1.6 Mbit/s	high- speed  (needs termination)
1	40 m	1.0 Mbit/s	
2	130 m	500 kbit/s	
3	270 m	250 kbit/s	
4	530 m	125 kbit/s	
5	620 m	100 kbit/s	low-speed
6	1.300m	50 kbit/s	
7	3.300 m	20 kbit/s	
8	6.700 m	10 kbit/s	
9	10.000 m	5 kbit/s	

Figure 19: CAN speed index.



## 13.7 CAN bus interface

From Wiener RemoteControl manual:

CAN controller type: P80C592 (CAN 2.0A protocol)  
Physical Layer: differential according to ISO 11898  
Transceiver: PCA82C250, opto-isolated, rise and fall slope control  
CAN connector: 9-pin DSUB male according to CiA DS 102-1

Pin	Line	Comment
1	-	reserved by CiA
2 (10*)	CAN_L	CAN_L bus line (dominant low)
3 (9*)	GND	Ground
4	-	reserved by CiA
5	-	reserved by CiA
6	-	
7 (11*)	CAN_H	CAN_H bus line (dominant high)
8	-	reserved by CiA (failure signal)
9	-	

\* optional connection to 15 pin DSUB female  
connector (UEV 4020 VME Bins only)

Baudrates:

Max. Distance	Bit Rate	Type
10 m	1.6 Mbit/s	high- speed
40 m	1.0 Mbit/s	
130 m	500 kbit/s	
270 m	250 kit/s	
530 m	125 kbit/s	
620 m	100 kbit/s	low-speed
1300 m	50 kbit/s	
3300 m	20 kbit/s	
6700 m	10 kbit/s	
10.000 m	5kbit/s	

Figure 20: CAN bus interface.

## 13.8 Windows Updates

Windows updates are usually only applied between Runs to avoid undesired and unexpected side effects.

To apply new patches:

- Go to <https://cmf.web.cern.ch/cmf/>
- On the Named Set of Computers (NSC), click Edit Existing NSC.
- Select NSS and NSC (only one option available in both).
- Go to Package Collections.
- At the bottom of the page select NICE as the NSS Filter.
- Apply/Update the desired packages.
- Login in the Windows PCs and install the packages from the CMF icon that appears on the system tray.

## 13.9 DCS website update

To update DCS website, from CERN GPN, one needs to:

- Copy the website content to a local folder:
  - > `konqueror webdavs://dfs.cern.ch/dfs/Websites/c/compass-dcs`
  - Copy main folder
- Edit the website locally.
- Apply the changes to the online version.
- Change permissions if needed.

<https://compass-dcs.web.cern.ch>

<https://webservices.web.cern.ch/webservices/>